



A **PACCAR** COMPANY

# Warning Symbols Quick Reference Guide



HEST

Hot Exhaust

Keep vehicle a safe distance from combustible items



DPF

Diesel Particulate Filter

Perform regeneration



DEF

Diesel Exhaust Fluid

Fill DEF tank if gauge reads low level. Otherwise seek service immediately for DEF fluid quality or DEF equipment repair



CHECK ENGINE

Engine



MIL

Engine - Emissions



EMISSIONS SYSTEM

Emissions Related Engine Derate

- **Perform stationary regeneration**
- **Add DEF fluid**
- **Seek service at the next stop if the warning light is still on**

Any of the above icons may appear alone or together to alert of necessary action to be taken as soon as possible. They will start flashing to notify of the upcoming engine derate.



COOLANT TEMP

Stop vehicle and idle engine



ENGINE OIL PRESSURE

Stop the engine or the engine may automatically shutdown.



STOP ENGINE